



versa-tile
A division of -
Wet Area Solutions (Aust) Pty Ltd



Shower Tile-Over Tray Installation Guide

Please read instructions carefully before installing; failure to follow instructions voids warranty.

It is the responsibility of the installer of the shower tray to adhere to local building codes in relation to waterproofing and installation.

Importantly, it is the responsibility of the installer to ensure that a water tight seal exists between the tile tray and puddle flange.

It is the responsibility of the installer to check that water drains to the outlet. Place Tray in-situ and water test prior to adhering to substrate

www.wetareas.com.au

Visit our website to view video installation guide.

Technical drawings are also available on our website.

- 1 Preparation
- 2 For installation on timber/steel substrate } **IMPORTANT**—Check technical
For installation on concrete substrate } drawing or measure thickness
} of tray after trimming to ensure
} correct depth for level entry
- 3 Waste connection (to be connected only by a licensed plumber)
- 4 Trimming
- 5 Laying tray
- 6 Flashing
- 7 Wallboard - Caulking - Priming - Taping
- 8 Waterproofing

For technical support call us on 1300 526 879 or email sales@wetareas.com.au

For technical drawings visit our website www.wetareas.com.au

Versatile Products, a division of Wet Area Solutions (Aust) Pty Ltd


5 Kim Ct, North Geelong VIC 3215 ABN: 99 630 203 673

4 Trimming

Tile tray is supplied with 3 or 4 lips to provide more choice for installation positioning.
Use appropriate tool (eg, Stanley knife/Jigsaw) to trim off unrequired sides.
Trimming will not affect performance/durability




5 Laying Tray



Use the suggested adhesive and apply to substrate as per manufacturers instructions.
Place tray directly over adhesive and lower into position.
Place 4 x 20 kg bags (eg, cement) to ensure adhesion and leave to cure, typically overnight.

6 Flashing




Care must be used when handling flashing to ensure correct fit. Avoid twisting/bending. Flashing is pre-fitted in factory, however it may require gentle manipulation to achieve proper fit.
Silicon, then place flashing.
Use galvanised clout nails to attach flashing, one per stud. Must be attached to each stud. Silicon nail heads.




7 Wallboard - Caulking - Priming - Taping

Run a bead of silicon on flashing 'step'. Install waterproof board directly on top of flashing 'step'.
Caulk ALL openings/joins.
Prime surface of tray,
Use waterproof tape over the caulked opening between the tile tray and the tile underlay and completely over join between wallboard and tray.



8 Waterproofing

Our Tile-Over Tray doesn't require a waterproof membrane. It is ready for tiling (using a tile adhesive that is compatible with the primer used)





versa-tile
A division of -
Wet Area Solutions (Aust) Pty Ltd



Suggested installation products to use.
These products have been laboratory tested.

**IMPORTANT : TRAY MUST BE THOROUGHLY SANDED PRIOR TO
APPLYING ANY PRODUCTS TO ENSURE CORRECT ADHESION**

For adhering tray to substrate

- Sikaflex – 11FC
- Ardex RA88
- Dunlop Builders Bond
- Selleys Proseries
- Selleys 3 in 1
- Mapeflex PU45

For surface priming

- Aqua Blok moisture seal
- Ardex WPM300 + Broadcast Sand
- Ardex Abapoxy + Broadcast Sand
- Ardex P9 Single Part Primer
- Gripset Betta Prime All
- Dunlop Primer & Additive

For tile adhesion

- Prohesive Ultrapro (also known as) MCB A100
- Ardex WA100
- Ardex Abaflex X77 +/- E90
- Ardex Abaflex X18 +/- E90
- Ardex STS8 + E90
- Dunlop Tile-All
- Mapei Kerapoxy 410

For expansion joints

- Ardex CA20P
- Mapei Mapeflex PU45
- Selleys Pro Series

For sealing over expansion joints

- Gripset/Betta peel & seal tape
- Ardex waterproofing detail tape